



American Dynamics
From Tyco Security Products

KNOWLEDGE

Applies To: Illustra 400

Article ID: AD-KB--000026

Version:

Published: 09/18/2014

Illustra 400 Simulated Menus

The following article provides a simulated display of the camera menus for reference when the actual equipment may not be available.

If you have any questions regarding this Knowledge Article, please contact American Dynamics Technical Support.
North America: (800) 507-6268;

Latin America and Caribbean: http://www.americandynamics.net/Support/contact_technical_support.aspx

Europe, Middle East and Africa: http://www.americandynamics.net/Support/contact_technical_support.aspx

Asia Pacific: http://www.americandynamics.net/Support/contact_technical_support.aspx

Information provided by American Dynamics is believed to be accurate and reliable. However, no responsibility is assumed by American Dynamics for its use, nor any infringements of other rights of third parties which may result from its use. No license is granted by implications or otherwise under any patent rights of American Dynamics.

PLEASE NOTE: If you would like to unsubscribe from receiving electronic communications from Tyco Security Products, you can do so by emailing TSPOptOUT@tycoint.com. Contact us at tspinfo@tycoint.com or by writing to: Sales Support Team, Tyco Security Products, 3301 Langstaff Road, Concord, ON L4K 4L2 for more information regarding this request. Si vous souhaitez vous désabonner et ne plus recevoir de communications électroniques de la part de Tyco Security Products, nous vous prions d'envoyer un courriel à TSPOptOUT@tycoint.com. Vous pouvez également nous joindre à l'adresse tspinfo@tycoint.com ou en nous écrivant à l'adresse: Sales Support Team, Tyco Security Products, 3301 Langstaff Road, Concord, ON L4K 4L2 pour obtenir plus d'informations concernant cette requête

American Dynamics

6 Technology Park Drive • Westford, MA 1886 USA

Tele: 978 577 4000 • Fax: 978 578 4392

www.americandynamics.net

tyco
Security Products



Video Profile **Profile-1(720x480)** ▼



[Image](#)
[Network](#)
[System](#)
[Application](#)
[Storage](#)
[Status](#)

Network

[PPPoE](#)
[Port Detail](#)
[Traffic](#)
[Dynamic DNS](#)
[HTTPS](#)
[Access List](#)

NETWORK SETUP

LAN SETTINGS

☐ Enable DHCP

IP address	192.168.100.152
Subnet mask	255.255.255.0
Default Gateway	192.168.100.254
Primary DNS	0.0.0.0

☒ Enable UPnP presentation

☐ Enable UPnP port forwarding

Forwarding Port	1024	Test
-----------------	------	----------------------

Forwarding Status UPnP : Forwarding is inactive

[Submit](#)

[Image](#)
[Network](#)
[System](#)
[Application](#)
[Storage](#)
[Status](#)
● **Device Info**
[Log](#)

DEVICE INFO

INFORMATION

Model Name	ADCi400-D011
Device Name	i400-ID-152
Time & Date	Fri Jan 10 22:04:35 2014
Firmware Version	3.06
HTML Version	3.0.98
Activex Version	2,0,0,55
MAC Address	00:30:46:01:16:C0
IP Address	192.168.100.152
IP Subnet Mask	255.255.255.0
Default Gateway	192.168.100.254
Primary DNS	0.0.0.0
PPPoE	Disable
DDNS	Disable
TV Output Mode	NTSC

[Image](#)[Network](#)[System](#)[Application](#)[Storage](#)[Status](#)[SD Card](#)

SD CARD

SD CARD

The SD Card Storage is unavailable or not formatted.

[Image](#)
[Network](#)
[System](#)
[Application](#)
[Storage](#)
[Status](#)
[Time and Date](#)
DI AND DO
DI and DO
[ICR](#)
[User](#)
[Maintenance](#)
[Upgrade Firmware](#)

DI AND DO

Digital Input 1: The active state is **N.O.** ; the current state detected is **Open**

Digital Output 1: The active state is **N.O.**

LED

LED ☒ On ☐ Off

VIDEO OUTPUT

VIDEO OUTPUT ☒ On ☐ Off

OSD OUTPUT ☐ On ☒ Off

[Image](#)
[Network](#)
[System](#)
[Application](#)
[Storage](#)
[Status](#)
[Time and Date](#)
[DI and DO](#)
[ICR](#)
[User](#)
[Maintenance](#)
[Upgrade Firmware](#)

ICR

ICR

Removable IR-Cut filter trigger condition:

- ☒ Automatic
- ☐ Day mode
- ☐ Night mode
- ☐ Schedule mode

Day mode(24hr)

 From To

IR LIGHT

IR LIGHT

- ☐ Off
- ☐ On
- ☒ Sync. With ICR
- ☐ Schedule

IR Light On(24hr)

 From To

[Image](#)
[Network](#)
[System](#)
[Application](#)
[Storage](#)
[Status](#)
[Time and Date](#)
[DI and DO](#)
[ICR](#)
[User](#)
● [Maintenance](#)
[Upgrade Firmware](#)

MAINTENANCE

SYSTEM

Save To Local Hard Drive

Save Configuration

Load From Local Hard Drive

Browse...

Load Configuration

Restore To Factory Default

Restore Factory Default

Restore all settings to factory default except settings in

☐ Network Type ☐ Language

Reboot Device

Reboot Device

[Image](#)
[Network](#)
[System](#)
[Application](#)
[Storage](#)
[Status](#)

Time and Date

[DI and DO](#)
[ICR](#)
[User](#)
[Maintenance](#)
[Upgrade Firmware](#)

TIME AND DATE

TIME CONFIGURATION

Time Zone

Time Format
☐ Enable Daylight Saving

☒ Auto Daylight Saving

☐ Set date and time manually

Offset

	Month	Week	Day of week	Hour	Minutes
Start time	<input type="text" value="5"/>	<input type="text" value="1"/>	<input type="text" value="Sunday"/>	<input type="text" value="00"/>	<input type="text" value="00"/>
End time	<input type="text" value="10"/>	<input type="text" value="1"/>	<input type="text" value="Sunday"/>	<input type="text" value="00"/>	<input type="text" value="00"/>

AUTOMATIC TIME CONFIGURATION

☒ Synchronize with NTP Server

NTP Server

SET DATE AND TIME MANUALLY

☐ Set date and time manually

Year	<input type="text" value="2014"/>	Month	<input type="text" value="1"/>	Day	<input type="text" value="10"/>
Hour	<input type="text" value="21"/>	Minute	<input type="text" value="54"/>	Second	<input type="text" value="48"/>

[Image](#)
[Network](#)
[System](#)
[Application](#)
[Storage](#)
[Status](#)
[Time and Date](#)
[DI and DO](#)
[ICR](#)
[User](#)
[Maintenance](#)
● [Upgrade Firmware](#)

UPGRADE FIRMWARE

FIRMWARE INFORMATION

Current Firmware Version: 3.06
 Current Product Name: ADCi400-D011

UPGRADE FIRMWARE

File Path:

[Image](#)
[Network](#)
[System](#)
[Application](#)
[Storage](#)
[Status](#)
[Time and Date](#)
[DI and DO](#)
[ICR](#)
[User](#)
[Maintenance](#)
[Upgrade Firmware](#)

USER

USER LIST

admin:Admin

[Delete User](#)

ADD/MODIFY USER

User Name :

maximum 20 users

Password:

maximum 63 characters

Confirm:

Authority:

☒ Admin
 ☐ Operator
 ☐ Viewer

[Add/Modify User](#)

[Image](#)
[Network](#)
[System](#)
[Application](#)
[Storage](#)
[Status](#)
[Language](#)
[Motion Detection](#)
● [Event](#)

EVENT SETUP

SERVER

Name	Type	Address/Location
Add	▼	Delete

MEDIA

Name	Type	Source
Add	▼	Delete

EVENT

Name	Status	Sun	Mon	Tue	Wed	Thu	Fri	Sat	Time	Trigger
Add	▼									Delete

RECORDING

Name	Status	Sun	Mon	Tue	Wed	Thu	Fri	Sat	Time	Source	Destination
Add	▼										Delete

[Image](#)[Network](#)[System](#)[Application](#)[Storage](#)[Status](#)**Language**

Motion Detection

Event

LANGUAGE SETUP**LANGUAGE SETTING**

Language:

English(English)



Image

Network

System

Application

Storage

Status

Language

Motion Detection

Event

MOTION DETECTION

LIVE VIDEO

☒ Enable Video Motion



☐ Sensitivity

80 0~100%

Percentage

1 0~100%

Submit

[Image](#)
[Network](#)
[System](#)
[Application](#)
[Storage](#)
[Status](#)
[Image](#)
[Audio and Video](#)
[Privacy Mask](#)

AUDIO AND VIDEO

VIDEO PROFILE 1

Mode H.264 ▾
 Frame size 720x480 ▾
 Intra Frame Period 30 ▾
 Maximum frame rate 30 ▾
 Video quality
 Constant bit rate ☒ 2M ▾
 Fixed quality ☐ Medium ▾

VIDEO PROFILE 2

Mode JPEG ▾
 Frame size 896x720 ▾
 Maximum frame rate 15 ▾
 Video quality High ▾

AUDIO SETTINGS

Encoding G.711 ▾
☐ Audio Mechanism Setting
 ☒ Audio Mic Gain 20dB ▾
 ☐ Line IN 0dB ▾
☐ Enable audio out
 Audio out volume level 10 ▾

[Image](#)
[Network](#)
[System](#)
[Application](#)
[Storage](#)
[Status](#)
[Image](#)
[Audio and Video](#)
[Privacy Mask](#)

PRIVACY MASK AREA OF VIDEO SETTING

PRIVACY MASK AREA OF VIDEO SETTING



Privacy mask: mask 3 privacy area(s) on video.
 Click the right mouse button on the video control to show the popmenu.
 Press the left mouse button, drag and drop to set the privacy area.
 Privacy area can be enabled or disabled.
 After you finish all privacy mask settings, click the Save button.

[Image](#)
[Network](#)
[System](#)
[Application](#)
[Storage](#)
[Status](#)
[Network](#)
[PPPoE](#)
[Port Detail](#)
[Traffic](#)
[Dynamic DNS](#)
[HTTPS](#)
● [Access List](#)

ACCESS LIST

ALLOW LIST

Start IP address

End IP address

Add

Delete allow list

Delete

DENY LIST

Start IP address

End IP address

Add

Delete deny list

Delete

[Image](#)
[Network](#)
[System](#)
[Application](#)
[Storage](#)
[Status](#)
Network

PPPoE

Port Detail

Traffic

Dynamic DNS

HTTPS

Access List

DYNAMIC DNS

DYNAMIC DNS SETTING

Enable DDNS

☐

Server Address

www.DynDNS.org

<<

www.DynDNS.org



Host Name

User Name

Password

Verify Password

Timeout

24

(hours)

Status

Inactive

Submit

[Image](#)
[Network](#)
[System](#)
[Application](#)
[Storage](#)
[Status](#)
[Network](#)
[PPPoE](#)
[Port Detail](#)
[Traffic](#)
[Dynamic DNS](#)
[HTTPS](#)
[Access List](#)

HTTPS

HTTPS

☐ Enable secure HTTPS connection

Create certificate settings

- ☐ Create self-signed certificate automatically
- ☐ Create self-signed certificate manually
- ☐ Create certificate request and install

 Create certificate: [Create](#)

CERTIFICATE INFORMATION

Status

No installed

[CSR Property](#)
[Certificate Property](#)
[Remove](#)
[Submit](#)

[Image](#)
[Network](#)
[System](#)
[Application](#)
[Storage](#)
[Status](#)
Network

PPPoE

Port Detail

Traffic

Dynamic DNS

HTTPS

Access List

PORT DETAIL
HTTP

HTTP port

Access name for stream1

Access name for stream2

HTTPS

HTTPS port

RTSP

RTSP port

Access name for stream1

Access name for stream2

[Image](#)[Network](#)[System](#)[Application](#)[Storage](#)[Status](#)[Network](#)[PPPoE](#)[Port Detail](#)[Traffic](#)[Dynamic DNS](#)[HTTPS](#)[Access List](#)

PPPoE

PPPoE SETTINGS

☒ Enable ☐ Disable

User Name

Password

Confirm password

Status

Inactive

[Image](#)
[Network](#)
[System](#)
[Application](#)
[Storage](#)
[Status](#)
[Network](#)
[PPPoE](#)
[Port Detail](#)
[Traffic](#)
[Dynamic DNS](#)
[HTTPS](#)
[Access List](#)

TRAFFIC

TRAFFIC

Maximum Upload Bandwidth: Kilobytes Per Second

Maximum Download Bandwidth: Kilobytes Per Second

* Due to TCP transmission protection, we have a minimal threshold in QoS control (16KB) to avoid socket lockup. Too little bandwidth (less than 16KB per second) will cause some sockets to disconnect easily.

[Image](#) |

[Network](#) |

[System](#) |

[Application](#) |

[Storage](#) |

[Status](#)
Image
[Audio and Video](#)
[Privacy Mask](#)
IMAGE SETUP
VIEWER TYPE

Viewer Type

- ☐ AJAX
☒ ActiveX

IMAGE SETTINGS


- AGC ☒ 32x ▾
 Exposure Time ☒ Auto ▾
 Mirror ☒ On ☐ Off
 Flip ☒ On ☐ Off
 White Balance Auto ▾ Save
 Brightness 128 ▾
 Contrast 128 ▾
 Saturation 128 ▾
 Sharpness 128 ▾
 WDR Level 4 ▾

Reset Default

DEVICE SETTING

- Device Name maximum 63 characters
☐ Enable OSD
 Timestamp Label maximum 63 characters
 Timestamp Location UPPER LEFT ▾

Submit

[Image](#)
[Network](#)
[System](#)
[Application](#)
[Storage](#)
[Status](#)
[Device Info](#)
[Log](#)

SYSTEM LOG

CURRENT LOG

1. 01-29-2014 21:43:56 admin LOGIN OK FROM 192.168.100.206
2. 01-29-2014 21:43:56 MOTION STOPPED
3. 01-29-2014 21:43:46 IP CAMERA Received MOTION Trigger
4. 01-29-2014 21:43:39 SYSTEM SET IR LIGHT OFF
5. 01-29-2014 21:43:33 SYSTEM BOOTING
6. 01-29-2014 21:42:24 admin LOGIN OK FROM 192.168.100.206
7. 01-29-2014 20:27:28 admin LOGIN OK FROM 192.168.100.144
8. 01-29-2014 14:39:04 MOTION STOPPED
9. 01-29-2014 14:38:54 IP CAMERA Received MOTION Trigger
10. 01-29-2014 14:37:11 MOTION STOPPED
11. 01-29-2014 14:37:07 IP CAMERA Received MOTION Trigger
12. 01-29-2014 14:35:51 MOTION STOPPED
13. 01-29-2014 14:35:47 IP CAMERA Received MOTION Trigger
14. 01-29-2014 14:32:51 MOTION STOPPED
15. 01-29-2014 14:32:45 IP CAMERA Received MOTION Trigger
16. 01-29-2014 14:32:36 MOTION STOPPED
17. 01-29-2014 14:31:58 IP CAMERA Received MOTION Trigger
18. 01-29-2014 14:31:43 MOTION STOPPED
19. 01-29-2014 14:31:41 IP CAMERA Received MOTION Trigger
20. 01-29-2014 14:31:41 MOTION STOPPED

[First Page](#)
[Previous 20](#)
[Next 20](#)
[Clear](#)
[Download](#)



Welcome to setup wizard - internet connection setup

This wizard will guide you through a step-by-step process to configure your new Camera and connect the camera to the internet. To set-up your camera motion detection settings, please click the Back button to close this wizard and re-open the motion detection setup wizard.

- Step 1: Setup LAN Settings
- Step 2: Setup Internet Settings
- Step 3: Setup DDNS Settings
- Step 4: Camera Name Settings
- Step 5: Setup Time Zone

Back

Next

Cancel